

iPICK presents an ability to quickly instruct and guide order picking using eight different user defined button light color combinations. The bright user defined LED button color (7, plus no light) will notify pick staff of the type of action expected at the product BIN location. The unique action color with informative large format displayed data or graphical image lowers training effort and increases pick accuracy. Depressing button confirms action / event.



Zone Master Display

Route, sequence, invoice, and account numbers displayed on ZONE MASTERS (beginning and end of a pick section/zone). Green LED can visually defines the ZONE area the picker is responsible



Check Picks Displayed

CHECK PICKS instructs pick staff to find miss picks. By looking back at Zone, illuminated Buttons such as Blue indicate what BIN was missed. Depressing button CONFIRMS pick.



21 Loose Copy Pick Displayed

Instruction at BIN level is complete with indication of type pick – LOOSE ONLY of 21 copies. A Red LED button might tell the pick staff to expect loose copies only in this pick. Current Invoice and Customer shown



Do Not Advance to next Pick Displayed

STOP – DO NOT ADVANCE to next pick as the picker in front of you is NOT FINISHED with current pick. This displays at ZONE MASTER when pick staff attempts to advance if you system setup indicates.




21 Loose Copy & 4 Bundles Pick Displayed

To facilitate LOOSE and BUNDLE picks from same BIN location, Violet or an alternate color is used with display indicating 21 loose and 4 bundles are to be picked. Current Invoice and Customer shown




No More Picks This Zone Displayed

END OF PICK displays to inform pick staff that the current container is completed. The display is illuminated with a Cyan colored display or other selected color indicating pick completion to picker.



No Picks Displayed

NO PICKS have dashes through the display and no LED is lit. This helps pick staff eliminate looking at these BINS speeding the pick staff to illuminated beacons only.



No More Picks – Close Box Displayed

CLOSE BOX is messaged for action of closing the box and potentially sending to “quick out” path to quality control or pack out. Message may alternatively indicate confirmation of “box filled” response after delay release of button. White or alternate color LED button.